




1999-2003 Acura TL Brake Pad Replacement

A video tutorial on how to change the brake pads on a 1999-2003 Acura TL or Honda Accord.

Written By: eCuration



INTRODUCTION

If you are experiencing poor braking performance and or a loud noise when braking, then it may be time for you to replace your front brake pads.

*for non Brembo applications.

Follow this video tutorial by YouTuber [BundysGarage](#) to complete the replacement yourself.

Safety

If this is your first time working on a vehicle read our [safety tips](#) before proceeding.



TOOLS:

- [Hydraulic Floor Jack](#) (1)
- [Jack Stand](#) (1)
- [3/8" Breaker Bar](#) (1)
- [3/8" Drive Ratchet](#) (1)
- [Socket 19mm](#) (1)
- [14 mm socket](#) (1)
- [12 mm Socket](#) (1)
- [14mm Wrench](#) (1)
- [12mm Wrench](#) (1)
- [6 Inch C-Clamp](#) (1)
- [Hammer](#) (1)
- [Anti-Seize Lubricant](#) (1)
- [Torque Wrench](#) (1)



PARTS:

- [Front Brake Pads](#) (1)

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-10-27 04:35:28 AM.